## Customizing Your Lexus

**Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.**

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

| Item | Function | Default setting | Customized setting |
| --- | --- | --- | --- |
| Smart access system with push-button start | Smart access system with push-button start | ON | OFF |
| | Operation signal (Emergency flashers) | ON | OFF |
| | Operation signal (Buzzer) | ON | OFF |
| Wireless remote control | Wireless remote control | ON | OFF |
| | Unlocking operation | Driver's door unlocked in one step, all doors unlocked in two steps | All doors unlocked in one step |
| | Automatic door lock function to be activated if door is not opened after being unlocked | ON | OFF |
| | Time elapsed before automatic lock function is activated if door is not opened after being unlocked | 60 seconds | 30 seconds |
| | | | 120 seconds |
| | Operational signal (Emergency flashers) | ON | OFF |
| | Operational signal (Buzzer) | ON | OFF |
| | Door lock buzzer | ON | OFF |
| | Trunk unlocking operation | Push and hold | Push twice |
| | | | One short push |
| | Panic function | ON | OFF |

| Item | Function | Default setting | Customized setting |
|---|---|---|---|
| Door lock | Speed-detecting automatic door lock function | OFF | ON |
| | Opening driver's door unlocks all doors. | OFF | ON |
| | Shifting gears to P unlocks all doors. | ON | OFF |
| | Shifting gears to position other than P locks all doors. | ON | OFF |
| | Unlocking using a key | Driver's door unlocked in one step, all doors unlocked in two steps | All doors unlocked in one step |
| Trunk | Power trunk opener and closer function | ON | OFF |
| Power windows | Mechanical key linked operation | ON | OFF |
| | Mechanical key linked operation | Open and close | Open only<br>Close only |
| | Wireless remote control linked operation | ON | OFF |
| | Linked entry operation | ON | OFF |
| Moon roof | Mechanical key linked operation | ON | OFF |
| | Mechanical key linked operation | Open and close | Open only<br>Close only |
| | Linked operation of components when door key is used | Slide only | Tilt only |
| | Wireless remote control linked operation | ON | OFF |
| | Linked operation of components when wireless remote control used | Slide only | Tilt only |
| | Linked entry function | ON | OFF |

| Item | Function | Default setting | Customized setting |
|---|---|---|---|
| Automatic light control system | Light sensor sensitivity | Level 3 | Levels 1 to 5 |
| | Time elapsed before headlights automatically turn off after doors are closed | 30 seconds | 0 seconds |
| | | | 60 seconds |
| | | | 90 seconds |
| Lights | Daytime running light system (U.S.A. only) | ON | OFF |
| Intuitive parking assist-sensor | Buzzer volume | Level 3 | Level 1 to 5 |
| | Distance at which the front and back sensors detect an obstacle | Level 1 | Level 2 |
| Illumination | Time elapsed before lights turn off | 15 seconds | 7.5 seconds |
| | | | 30 seconds |
| | Operation when the doors are unlocked | ON | OFF |
| | Operation after the engine switch is turned OFF | ON | OFF |
| | Footwell lighting | ON | OFF |
| | Shift lever lighting | ON | OFF |
| | Outer foot lights | ON | OFF |
| Seat belt reminder | Vehicle speed linked seat belt reminder buzzer | ON | OFF |

## Multi-information display

| Country | Available languages |
|---|---|
| U.S.A. | English and Spanish |
| Canada | English, French, German, Spanish and Italian |

**Your Lexus dealer**

Your Lexus dealer will provide quality maintenance and any other assistance you may require.

If there is not a Lexus dealer near you, please call the following number:

■ U.S. OWNERS

● In the U.S. mainland or Canada:
Lexus Roadside Assistance
1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)

● In Hawaii:
Servco Automotive Roadside Assistance/Customer Services
1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)

■ CANADIAN OWNERS

● In Canada or the U.S. mainland:
Lexus Roadside Assistance/Customer Service
1-800-26-LEXUS or 1-800-265-3987 (Toll-Free)

Please access our **websites** for further information.

● The U.S. mainland: **www.lexus.com**
● Hawaii: **www.servcolexus.com**
● Canada : **www.lexus.ca**